




FULL AUTOMATIC TWIST LOCK FA-8

Setting (Before containr loading)




Insert upper fixed cone projecting into corner fitting and turn to counterclockwise. And then twist lock is automatically locked by locking mechanism.





After stack container twist lock is locked automatically.

Take off (After container discharge)



Heave up container



Pushing lock pin to left, turn twist lock clockwise.

Twist lock comes down.